

Firmware upgrade Instruction

Preparation:

- Make sure your device is more than 75% charged.
- Make sure your computer has Internet access.
- A SD card that is empty.

Upgrade procedure

1. Download firmware file to the computer

Click on the Download icon at the top of the screen to download the new firmware package to your computer.



2. Transfer the file from the computer to the device

- I. On the computer, unzip the downloaded .zip firmware file.
- II. Copy and paste the unzipped files from the computer to the root directory of the SD card.
- III. Power off the tablet and insert the SD card into the SD card slot of the tablet.

3. Upgrade the firmware

- I. Press and hold the Power button until the Android robot icon is displayed.
- II. The firmware upgrade progress automatically starts. The upgrade progress is shown by a progress bar.
- III. When the upgrade is completed, the tablet would restart automatically.

4. Confirm successful update

On the Home screen of the device, go to [Settings] > [About tablet]. Check the software version number

Note:

- During the upgrading process, **DO NOT** touch the screen or press any button.
- During the upgrading process, keep the device powered on.